
About this document

This document outlines the characteristics and operation of the QPC422 Tone Detector Card.

References

See the *Meridian 1 planning and engineering guide* for the following documents:

- *Spares planning* (553-3001-153)
- *Meridian 1 equipment identification* (553-3001-154)

For detailed procedures for installing and testing the tone detector card, see *Circuit card installation and testing* (553-3001-211) in the *Meridian 1 installation and maintenance guide*.

For detailed description of the Tone Detector application with the Automatic Trunk Maintenance (ATM) feature, refer to *Automatic trunk maintenance* (553-2751-104).

See the *X11 input/output guide* (553-3001-400) for a description of all administration programs, maintenance programs, and system messages.